



# Xiaomi Yi Front Panel Replacement

This guide will show you how to remove the front panel on your Xiaomi Yi action camera.

Written By: William Zipperer



## INTRODUCTION

The front panel is attached to the main case of the camera. It can be removed with a small blue plastic opening tool.


The front panel does not include the lens, but does allow you access to other internal parts of the camera; or, to replace a damaged front panel.



### TOOLS:


- [iFixit Opening Tools](#) (1)
-

## Step 1 — Battery



- Push the battery door switch to the left.
- Lift the battery door up.


## Step 2



- Lift the battery tab up.
- Remove the battery by pulling the removal tab.




## Step 3 — Front Panel



- Introduce the plastic opening tool into any of the sides of the camera.
- Pry with the plastic opening tool at the seam between the front and the back panel.

## Step 4



- Slide prying tool along the seam until front panel is fully separated from the back panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 07:00:55 PM.